

www.fabricatorguide.com PIPE BRANCH REINFORCING PAD TABLE 90° DEGREE D.. IN MM															
Pipe size	C 1	C 2	C 3	C 4	C 5	C 6		L 1	L 2	L 3	L 4	L 5	L 6		R
4" × 4"	25	46	62	69	138	242		23	43	57	62	124	228		52
4" × 6"	25	47	61	66	132	236		23	43	57	62	124	228		52
4" × 8"	25	47	61	66	132	236		23	43	57	62	124	228		52
4" × 10"	25	47	61	66	132	236		23	43	57	62	124	228		52
4" × 12"	25	47	61	66	132	236		23	43	57	62	124	228		52
4" × 14"	25	47	61	66	132	236		23	43	57	62	124	228		52
4" × 50"	25	47	61	66	132	236		23	43	57	62	124	228		52
6" × 6"	36	67	92	103	206	364		34	63	82	89	178	336		79
6" × 8"	36	66	88	96	192	350		34	63	82	89	178	336		79
6" × 10"	36	66	87	94	188	346		34	63	82	89	178	336		79
6" × 12"	36	66	87	94	188	346		34	63	82	89	178	336		79
6" × 14"	36	66	87	94	188	346		34	63	82	89	178	336		79
6" × 16"	36	66	87	94	188	346		34	63	82	89	178	336		79
6" × 50"	36	66	87	94	188	346		34	63	82	89	178	336		79