

www.fabricatorguide.com PIPE BRANCH REINFORCING PAD TABLE 90° DEGREE D.. IN MM													
Pipe size	C 1	C 2	C 3	C 4	C 5	C 6	L 1	L 2	L 3	L 4	L 5	L 6	R
32" × 32"	162	319	464	544	1088	1891	157	290	380	411	822	1625	401
32" × 34"	162	315	447	510	1020	1822	157	290	380	411	822	1625	401
32" × 36"	161	312	435	489	978	1780	157	290	380	411	822	1625	401
32" × 38"	161	310	427	476	952	1754	157	290	380	411	822	1625	401
32" × 40"	161	308	421	467	934	1736	157	290	380	411	822	1625	401
32" × 42"	161	307	417	460	920	1722	157	290	380	411	822	1625	401
32" × 44"	160	305	413	454	908	1710	157	290	380	411	822	1625	401
32" × 46"	160	304	410	450	900	1702	157	290	380	411	822	1625	401
32" × 48"	160	303	407	446	892	1694	157	290	380	411	822	1625	401
32" × 50"	160	302	405	443	886	1688	157	290	380	411	822	1625	401
32" × 52"	160	302	403	441	882	1684	157	290	380	411	822	1625	401
32" × 54"	160	301	401	438	876	1678	157	290	380	411	822	1625	401
32" × 56"	160	301	400	437	874	1676	157	290	380	411	822	1625	401
32" × 58"	160	300	399	435	870	1672	157	290	380	411	822	1625	401

www.fabricatorguide.com PIPE BRANCH REINFORCING PAD TABLE 90° DEGREE D.. IN MM													
Pipe size	C 1	C 2	C 3	C 4	C 5	C 6	L 1	L 2	L 3	L 4	L 5	L 6	R
34" × 34"	172	339	494	591	1182	2036	167	308	403	436	872	1727	427
34" × 36"	172	335	476	545	1090	1944	167	308	403	436	872	1727	427
34" × 38"	171	332	464	523	1046	1900	167	308	403	436	872	1727	427
34" × 40"	171	330	456	509	1018	1872	167	308	403	436	872	1727	427
34" × 42"	171	328	449	499	998	1852	167	308	403	436	872	1727	427
34" × 44"	171	326	444	491	982	1836	167	308	403	436	872	1727	427
34" × 46"	170	325	440	485	970	1824	167	308	403	436	872	1727	427
34" × 48"	170	323	436	480	960	1814	167	308	403	436	872	1727	427
34" × 50"	170	322	434	476	952	1806	167	308	403	436	872	1727	427
34" × 52"	170	322	431	472	944	1798	167	308	403	436	872	1727	427
34" × 54"	170	321	429	470	940	1794	167	308	403	436	872	1727	427
34" × 56"	170	320	427	467	934	1788	167	308	403	436	872	1727	427
34" × 58"	170	319	426	465	930	1784	167	308	403	436	872	1727	427

www.fabricatorguide.com PIPE BRANCH REINFORCING PAD TABLE 90° DEGREE D.. IN MM													
Pipe size	C 1	C 2	C 3	C 4	C 5	C 6	L 1	L 2	L 3	L 4	L 5	L 6	R
36" × 36"	182	359	524	628	1256	2160	176	326	427	462	924	1828	452
36" × 38"	182	355	505	580	1160	2064	176	326	427	462	924	1828	452
36" × 40"	181	352	493	556	1112	2016	176	326	427	462	924	1828	452
36" × 42"	181	349	484	541	1082	1986	176	326	427	462	924	1828	452
36" × 44"	181	347	477	530	1060	1964	176	326	427	462	924	1828	452
36" × 46"	180	346	472	522	1044	1948	176	326	427	462	924	1828	452
36" × 48"	180	344	467	515	1030	1934	176	326	427	462	924	1828	452
36" × 50"	180	343	463	510	1020	1924	176	326	427	462	924	1828	452
36" × 52"	180	342	460	506	1012	1916	176	326	427	462	924	1828	452
36" × 54"	180	341	458	502	1004	1908	176	326	427	462	924	1828	452
36" × 56"	180	340	455	499	998	1902	176	326	427	462	924	1828	452
36" × 58"	180	339	453	496	992	1896	176	326	427	462	924	1828	452